

## Assembly Manual



### ■ What's In The Box

Please inspect the contents of your shipped package to ensure you have received everything that is listed below.



**Support Jacket**



**Bag Packing**

---

All rights reserved.

No part of this document may be reproduced, stored in a retrieval system, or transmitted by any form or by any means, electronic, mechanical, photo-copying, recording, or otherwise, except as may be expressly permitted by the applicable copyright statutes or in writing by the Publisher.

## Flowline Professional Series Setup

**NOTE:** It is recommended to attach the minimum required weight for pulling down the balancing rope to ensure proper operation of your Flycam Flowline system.

**NOTE:** Using **Placid (FLCM-FLN-PLA)** with this Flowline model will impact the minimum and maximum payload capacities.

### Support Arm Assembly

- Attach the Support Arm to the Support jacket using a simple push-fit technique.



**Feature:** The Support Arm allows 360° rotation to capture shots with incredible freedom of movement.



### Support Arm Height Adjustment


- Loosen all four Adjustment knobs provided on the back of the Support Jacket.
- Then, adjust the height of the Support Arm by moving it upwards or downwards.



- Once the Support arm is at the desired height, re-tighten all four Adjustment Knobs to secure the arm.





## Height Adjustable Support Arm




## Jacket Assembly

- Wear the Support Jacket.
- Attach both (Left / Right) padded waist belt with Velcro.
- Now, tighten the buckles provided at the waist and chest.
- Adjust them to your comfort.



## Camera Mounting

- Loosen the knob of the Camera Hook.
- Push the Camera Hook upwards.



- Now, carefully place the Camera (Not Included) in the Camera Hook.


**NOTE:** When filming, you might have to manually pull the Camera setup up or down as per your convenience.



- Re-tighten the knob to ensure slip-free attachment.



- Loosen the knob and adjust the position of the Camera by sliding the knob forward or backward.



- Your setup is ready to use.

## YOUR FLYCAM FLOWLINE PROFESSIONAL SERIES ALL DRESSED UP AND READY TO GO!



(SHOWN WITH OPTIONAL ACCESSORIES)

**Warranty:** We offer a one-year warranty on our products from the date of purchase. During this period, we will repair the product free of charge for labor or parts. The warranty does **not** cover transportation costs or products that have been misused or accidentally damaged. All warranty repairs are subject to inspection and evaluation by our team.

**Liability:** We are not liable for any damage caused by third-party products, mishandling during transit, accidents, misuse, neglect, or unauthorized servicing of the product.

**Contact Us:** In case of any dissatisfaction, please contact us immediately. We are committed to providing the utmost support and care to ensure your satisfaction with our product.