

PROAIM

Flycam Arm Brace Support (FLCM-AB)



All rights reserved.

No part of this document may be reproduced, stored in a retrieval system, or transmitted by any form or by any means, electronic, mechanical, photo-copying, recording, or otherwise, except as may be expressly permitted by the applicable copyright statutes or in writing by the Publisher.

Assembling Setup

- Pull out the metal support base from the arm brace.



- Unfasten each strap and fully open the brace so all Velcro straps hang freely.



- Detach and pull out all elastic Velcro straps from the brace.



- Pull the metal arm support cover out of the arm brace.



- Insert the metal arm support inside the metal arm



- Place your arm onto the metal base support.



- Reattach the elastic Velcro straps to the metal base support cover from both sides.



- Wrap the arm brace around your arm and fasten all Velcro straps

Note: Tighten the straps firmly enough to secure the brace, but not so tight that it restrict blood circulation. Once comfortable, your arm brace is ready for use.



- Place your stabilizer onto the arm base support—your setup is now complete.



YOUR FLYCAM ARM BRACE SUPPORT ALL DRESSED UP AND READY TO GO!



(SHOWN WITH OPTIONAL ACCESSORIES)

Warranty: We offer a one-year warranty on our products from the date of purchase. During this period, we will repair the product free of charge for labor or parts. The warranty does not cover transportation costs or products that have been misused or accidentally damaged. All warranty repairs are subject to inspection and evaluation by our team.

Liability: We are not liable for any damage caused by third-party products, mishandling during transit, accidents, misuse, neglect, or unauthorized servicing of the product.

Contact Us: In case of any dissatisfaction, please contact us immediately. We are committed to providing the utmost support and care to ensure your satisfaction with our product.