

Assembly Manual



What's In The Box

Please inspect the contents of your shipped package to ensure you have received everything that is listed below.



Comfort Vest (Front)



Comfort Vest (Back)



Comfort Arm



Arm Vest Connectors



Hip Pad



2 x Bush 19mm
(OD-22mm)



2 x L-Type Allen Keys
(Size: 3/16" & 3mm)


All rights reserved.

No part of this document may be reproduced, stored in a retrieval system, or transmitted by any form or by any means, electronic, mechanical, photo-copying, recording, or otherwise, except as may be expressly permitted by the applicable copyright statutes or in writing by the Publisher.

Comfort Vest & Comfort Arm



Comfort Vest



Comfort Arm

Comfort Arm & Vest Setup

Comfort Vest Assembly

- Attach the front and back sections of the comfort vest using the push-fit buckles on both sides at the top.




- Wear the vest and secure the push-fit buckle around your waist as shown in the image.

Feature: Push-fit buckles allow quick vest removal during short breaks.



- Adjust the vest straps for a comfortable fit by tightening or loosening them as needed.



Hip Pad Assembly

- Adjust the hip pad strap for a comfortable fit by tightening or loosening it as needed.



- Attach the hip pad to either side by fastening the push-fit buckles, then tighten the strap for a secure fit.




NOTE: We've also included waist padding made from fiber sheets, ensuring a more personalized fit.




Chest Plate Height Adjustment

- Use the pull pin to adjust the plate's height to your desired position.



Fits All Body Types
Easy Height Adjustment up to 16cm



Arm Vest Connector Mounting

- Loosen the knob of the sturdy connector, as shown in the image.
- Then, insert the arm vest connector of the comfort arm into the sturdy connector.



- Once inserted, re-tighten the knob on the sturdy connector.
- Your arm vest connector is now securely attached, as shown in the image.



Comfort Arm Mounting On Arm Vest Connector

- Loosen the adjustment knob on the comfort arm and securely attach the arm to the arm vest connector.



- Once the comfort arm is mounted, tighten the knob securely.



Bush Mounting

NOTE: If you are using a Stabilizer or Handheld Stabilizer, you will need to replace the Spool Adapter post.



- Mount the bush onto the spool adapter.




Stabilizer Mounting

- Insert the Flycam Stabilizer (not included) into the spool adapter of the comfort arm.
- The Flycam Stabilizer is now properly attached to the comfort arm, as shown in the image.



- Now mount your camera (not included) onto the stabilizer.

Feature: Turn the knob clockwise to set the angle of the arm at your desired fixed position, and turn it anti-clockwise for smooth gliding shots.



YOUR FLYCAM COMFORT ARM AND VEST FOR HANDHELD CAMERA ALL DRESSED UP AND READY TO GO!



(SHOWN WITH OPTIONAL ACCESSORIES)

Warranty: We offer a one-year warranty for our products from the date of purchase. Within this period, we will repair it without charge for labor or parts. The warranty doesn't cover transportation costs, nor does it cover a product subjected to misuse or accidental damage. Warranty repairs are subject to inspection and evaluation by us.

Liability: We are not liable for damage caused by products we do not supply or from mishandling in transit, accident, misuse, neglect, or lack of care of the product or service by anyone other than our company.

Contact Us: If you are dissatisfied, please contact us immediately. We promise our utmost support and care until you use our product.