

# Flowline Camera Support (FLCM-FLN-300N | 400N | 500N)

## Assembly Manual



### What's In The Box

Please inspect the contents of your shipped package to ensure you have received everything that is listed below.



All rights reserved.

No part of this document may be reproduced, stored in a retrieval system, or transmitted by any form or by any means, electronic, mechanical, photo-copying, recording, or otherwise, except as may be expressly permitted by the applicable copyright statutes or in writing by the Publisher.

## Flowline Setup

**NOTE:** It is recommended to attach the minimum required weight to pull down the balancing rope to ensure proper operation of your Flycam Flowline system.

**NOTE:** Using **Placid (FLCM-FLN-PLA)** or **Edge V1 (FLCM-EDGE-V1)** with this Flowline model will impact the minimum and maximum payload capacities.


- Join the Support Arm with the section on the Support Jacket using the simple push-fit technique.



- Slightly loosen all four Adjustment Knobs provided on the back of the Support Jacket to adjust the height of the Support Arm.



- Wear the Support Jacket and tighten the buckles provided at the waist and chest. Adjust until you find a comfortable fit.



- Adjust the Support Arms on both sides. This will fine-tune your jacket to a comfortable position and help distribute the weight evenly across your shoulders and hips



- Loosen the knob on the hook and attach the camera to it. Tighten the knob securely to ensure a slip-free connection.



**NOTE:** Leave a gap of approximately 2 cm (1") between the top of the Camera Hook and the Support Arm.



- Finally, attach one end of the Safety Belt to the camera and the other end to the Support Jacket for added safety and protection.



- When folding the Flycam Flowline, always ensure the upper part of the Support Arm is placed inside the hip/waist belt and the buckle is fastened. This will help prevent wear on the Suspension Line.



## YOUR FLYCAM FLOWLINE CAMERA SUPPORT ALL DRESSED UP AND READY TO GO!



(SHOWN WITH OPTIONAL ACCESSORIES)

**Warranty:** We offer a one-year warranty on our products from the date of purchase. During this period, we will repair the product free of charge for labor or parts. The warranty does **not** cover transportation costs or products that have been misused or accidentally damaged. All warranty repairs are subject to inspection and evaluation by our team.

**Liability:** We are not liable for any damage caused by third-party products, mishandling during transit, accidents, misuse, neglect, or unauthorized servicing of the product.

**Contact Us:** In case of any dissatisfaction, please contact us immediately. We are committed to providing the utmost support and care to ensure your satisfaction with our product.