



Flowline Master with Edge V1 Stabilization Arm (FLN-MSTR-EGV1)



All rights reserved.

No part of this document may be reproduced, stored in a retrieval system, or transmitted by any form or by any means, electronic, mechanical, photo-copying, recording, or otherwise, except as may be expressly permitted by the applicable copyright statutes or in writing by the Publisher.

What's In The Box

Please inspect the contents of your shipped package to ensure you have received everything that is listed below.



Flowline Edge V1 Stabilization Arm



Bag Packing

Features:



Flycam Flowline Master with Edge V1 Arm

Flowline Starter with Edge Setup

NOTE: It is recommended to attach the minimum required weight (4kg / 8lb) for pulling down the balancing rope to ensure proper operation of your Flycam Flowline system.

Support Bar Adjustment

- Loosen the knob of the Flowline Edge.



- After loosening the knob, remove it and pull the rod of Flowline Edge to open it.

Feature: Foldable Design of Flowline Edge makes it easier to store.




Edge V1 Arm mounting on Flycam Flowline Master Vest

- Properly attach the Edge to the flowline vest.




- After opening the Rod, insert the knob and properly tighten it, as shown in the image.


Feature: Tension adjustment knob to match your rig's weight, while the adaptable sliding knob adjusts the support rope to your unique filming needs.



- The Flowline Edge is fully assembled with the Stabilization Arm. The versatile belt system molds to fit all body types.



- Put on the support jacket and tighten the buckles provided at the waist and chest.



- Then, adjust the jacket as per your convenience.



Camera Mounting

- Attach the Camera (**Not Included**) to the hook and tighten using the provided knob to ensure a slip-free connection.



- Your setup is ready to use.




Adjust Camera Setup Position

- Loosen the knob at the support bar to adjust the camera setup position.



Adjust Camera Setup Position



Spring Tension Adjustment

- Loosen the knob at the Edge V1 arm to adjust the spring tension.

Feature: The tension adjustment knob allows you to fine-tune the arm's spring tension to your rig's weight, while the adaptable sliding knob adjusts the support rope to meet your unique needs.



Low / High Angle Shots



Capture Every Angle (180° Rotation)



**YOUR FLYCAM FLOWLINE MASTER WITH EDGE V1 STABILIZATION ARM
ALL DRESSED UP AND READY TO GO!**



(SHOWN WITH OPTIONAL ACCESSORIES)

Warranty: We offer a one-year warranty on our products from the date of purchase. During this period, we will repair the product free of charge for labor or parts. The warranty does **not** cover transportation costs or products that have been misused or accidentally damaged. All warranty repairs are subject to inspection and evaluation by our team.

Liability: We are not liable for any damage caused by third-party products, mishandling during transit, accidents, misuse, neglect, or unauthorized servicing of the product.

Contact Us: In case of any dissatisfaction, please contact us immediately. We are committed to providing the utmost support and care to ensure your satisfaction with our product.