

# PR◀AIM

## Cinema Arm & Vest for Handheld Camera Stabilizers (CV15-AV)



## What's In The Box

Please inspect the contents of your shipped package to ensure you have received everything that is listed below.



Cinema Vest



Cinema Arm



Hip Pad



Bag Packing

---

All rights reserved.

No part of this document may be reproduced, stored in a retrieval system, or transmitted by any form or by any means, electronic, mechanical, photo-copying, recording, or otherwise, except as may be expressly permitted by the applicable copyright statutes or in writing by the Publisher.

# INDEX

| <b>Sr. No</b> | <b>Particulars</b>                   | <b>Page No.</b> |
|---------------|--------------------------------------|-----------------|
| 1.            | Cinema Vest Assembly                 | 4-5             |
| 2.            | Hip Pad Assembly                     | 5               |
| 3.            | Cinema Arm Assembly                  | 6               |
| 4.            | Adjust Arm Spring Tension            | 7               |
| 5.            | Adjusting Arm's Position             | 7-8             |
| 6.            | Adjusting Arm's Movement             | 8               |
| 7.            | Zest Pro Electronic Stabilizer Setup | 9               |
| 8.            | Final Setup                          | 10              |


## Cinema Arm & Vest Setup

### Cinema Vest Assembly

- Attach the front and back sides of the Cinema Vest using the buckle.



- Repeat the process for the second Buckle.



- Wear the vest.



- Fasten the ratchet buckle at the waist.
- **Feature:** Unique ratchet buckle allows adjustable fitting.



- Lock the Ratchet Buckle properly.
- Repeat for the second buckle.



- Open the Velcro on the shoulder straps and pull as required.



- Press the Velcro firmly to secure the straps.
  - Repeat for the second shoulder strap.
- Note: You can tighten or loosen the Adjustment strap of the vest for optimal comfort.



- Adjust the height of the Slider Plate using the Pull Pin as needed.



## Hip Pad Assembly


- Attach the Hip Pad to your waist and overlap the Velcro on both sides for a secure fit.
- Note:** Ensure the hip straps remain horizontal on the pad and tighten evenly.



Note: We've also included fiber-sheet waist padding for a personalized fit.



## Cinema Arm Assembly



- Loosen the knobs on the Socket Block, as shown in the image.



- Insert the male connecting Socket of the Cinema Arm into the Socket Block.





- Re-tighten the knobs to secure the Cinema Arm.
- Your Cinema Arm should now be securely attached to the vest, ready for tension adjustments.




**Feature:**

1. Adjustable tension for optimal performance.
2. Dual-spring design for smooth operation.

**Adjust Arm Spring Tension**

Note: Always adjust the section closest to the stabilizer first, followed by the second section of the arm.

- Loosen the first Spring Tension Adjustment knob to balance the upper arm section, then re-tighten.
- Loosen the second knob to balance the lower arm section, then re-tighten.

**Adjusting Arm's Position**

- Loosen the knob and pull the Pull Pin.
- Remove the socket block and adjust it left or right, as shown in the image.



- Slide the socket block along the slider plate.



- Tighten the knob and lock the position with the pull pin.



**Feature:** The Arm can be comfortably operated by both right-handed and left-handed users.




## Adjusting the Arm's Movement

- For left/right movement, turn both knurled knobs until the arm moves smoothly according to the setup weight.



- For back-and-forth movement, adjust the arm locking knob until balanced.



- Setup is complete, and the arm is ready for smooth operation.



## Zest Pro Electronic Stabilizer Setup

**Note:** When attaching the stabilizer to the Arm and Vest, ensure the stabilizer's handle remains straight and aligned with the Arm's pin.

**Feature:** The Cinema Arm features a 16mm post for Stabilizers, making it compatible with most Stabilizers.

- Insert the Zest Pro Electronic Stabilizer (Not Included) into the 16mm Post of the Cinema Arm.



- The Zest Pro Stabilizer is properly attached to the Cinema Arm, as shown in the image.



## YOUR PROAIM CINEMA ARM & VEST FOR HANDHELD CAMERA STABILIZERS ALL DRESSED UP AND READY TO GO!



(SHOWN WITH OPTIONAL ACCESSORIES)

**Warranty:** We offer a one-year warranty for our products from the date of purchase. Within this period of time, we will repair it without charge for labor or parts. Warranty doesn't cover transportation costs, nor does it cover a product subjected to misuse or accidental damage. Warranty repairs are subject to inspection and evaluation by us.

**Liability:** We are not liable for damage caused by products that we do not supply or from mishandling in transit, accident, misuse, neglect, lack of care of the product, or service by anyone other than our company.

**Contact Us:** In case of any kind of dissatisfaction, please contact us immediately, and we promise our utmost support and care until you use our product.