



## Universal Plus Laptop Workstation Platform (WKST-UPL-02)




---

All rights reserved.

No part of this document may be reproduced, stored in a retrieval system, or transmitted by any form or by any means, electronic, mechanical, photo-copying, recording, or otherwise, except as may be expressly permitted by the applicable copyright statutes or in writing by the Publisher.

## What's In The Box

Please inspect the contents of your shipped package to ensure you have received everything that is listed below.



Base Platform



C-Stand Clamp



2 x 25mm  
L-brackets



2 x 12mm  
L-brackets



6 x Locking Knobs



4 x Robust Legs



6 x Washers



2 x 1mm  
Shim Set

2 x 3mm  
Shim Set

2 x 6mm  
Shim Set



1 x L-Type Allen Key  
(Size : 7/32mm)

## ■ Universal Plus Laptop Workstation Setup

### C-stand Clamp Mounting on Base Platform



- Loosen the bolt from the C-stand clamp using a 7/32mm Allen key and remove it.



- Mount the Base Platform onto the C-stand adapter.
- Insert the bolts, ensuring they align with the threads.



- Now tighten the bolt using a 7/32mm Allen key.



### Robust Legs Mounting

- Attach the robust legs to the corners of the workstation and secure them by twisting.





**Feature:** Four Support Feet allow for setting down the ring on flat ground without worrying about it falling.



## C-stand Clamp Mounting on C-Stand

- Loosen the knob on the C-stand adapter and mount it onto the baby pin of the C-stand.



- Now, tighten the adapter's knob to secure it properly.



- Place Your laptop (Not Included) on the workstation.

**Compatibility:** Laptop with 10-25mm thickness.



## Shims Mounting

- After placing the laptop on the workstation place the shims to increase the adjustable thickness of your laptop.
- Now place the L-bracket over the shims.



- Tighten and secure the L-brackets using the locking knob.

**NOTE:** Locking knobs are available in three sizes. You can use locking knobs according to the thickness of your laptop.




- Place Shims on both sides.
- Universal Laptop Workstation is now ready to use.



## ■ Tripod Ball Head Setup

- Loosen the knob of the ball head on the tripod stand (**Not Included**) and mount the base platform securely.



- After mounting the base platform, tighten the knob properly.
- Finally, the base platform is securely mounted on the tripod.



**NOTE:** This workstation easily accommodates a laptop with a thickness of 10-25mm. To ensure a secure setup, clamps are provided to affix the laptop to the platform.



## Mounts to Tripod / Stand

Arca Mount, Detachable 5/8 Baby Pin Clamp



Arca Mount



5/8 Baby Pin

## YOUR PROAIM UNIVERSAL PLUS LAPTOP WORKSTATION PLATFORM ALL DRESSED UP AND READY TO GO!



(SHOWN WITH OPTIONAL ACCESSORIES)

**Warranty:** We offer a one-year warranty on our products from the date of purchase. During this period, we will repair the product free of charge for labor or parts. The warranty does **not** cover transportation costs or products that have been misused or accidentally damaged. All warranty repairs are subject to inspection and evaluation by our team.

**Liability:** We are not liable for any damage caused by third-party products, mishandling during transit, accidents, misuse, neglect, or unauthorized servicing of the product.

**Contact Us:** In case of any dissatisfaction, please contact us immediately. We are committed to providing the utmost support and care to ensure your satisfaction with our product.