

Assembly Manual



What's In The Box

Please inspect the contents of your shipped package to ensure you have received everything that is listed below.



Bull Telescopic Gas Lift Bazooka



Ratchet Lock
Lever Handle



Bag Packing

All rights reserved.

No part of this document may be reproduced, stored in a retrieval system, or transmitted by any form or by any means, electronic, mechanical, photo-copying, recording, or otherwise, except as may be expressly permitted by the applicable copyright statutes or in writing by the Publisher.

Bull Telescopic Gas Lift Bazooka Setup

NOTE: The Bull Bazooka comes in two variants

1. **BZ-BULL-01**- Load Capacity: 20-45 kg / 44-99 lb

2. **BZ-BULL-02**- Load capacity: 10-20 kg / 22-44 lb

Ratchet Lock Lever Handle Mounting

- Attach the Ratchet lock lever handle to the bull bazooka & rotate 360° to secure it.



NOTE: Bull Bazooka allows excellent flexibility in camera positioning. Bazooka's height adjustment depends on the weight of the mounted product.



Bull Bazooka Mounting

- Mount the Bull bazooka on the euro mount **(Not Included)**.



- After mounting the bull bazooka, secure it using the Ratchet lock lever handle.



Camera Riser Mounting on Bull Bazooka

- Loosen the ratchet knob of the camera riser **(Not Included)** and mount it on the Bull bazooka.



- Re-tighten the Ratchet lock lever handle knob to secure it.



Camera Mounting

- Remove the castle ring from the fluid head **(Not Included)** and mount it on the height riser.



- After mounting the fluid head, attach the castle ring and securely re-tighten it.



- Now, mount your camera (Not Included) on the Fluid head.(Not Included)



YOUR PROAIM BULL TELESCOPIC GAS LIFT BAZOOKA ALL DRESSED UP AND READY TO GO!



(SHOWN WITH OPTIONAL ACCESSORIES)

Warranty: We offer one year warranty for our products from date of purchase. Within this period of time, we will repair it without charge for labor or parts. Warranty doesn't cover transportation costs nor does it cover a product subjected to misuse or accidental damage. Warranty repairs are subjected to inspection and evaluation by us.

Liability: We are not liable for damage caused by products that we do not supply or from mishandling in transit, accident, misuse, neglect, lack of care of the product, or service by anyone other than our company.

Contact Us: In case of any kind of dissatisfaction, please Contact us immediately and we promise our utmost support and care until you use our product.