

PROAIM

12ft Camera Crane Jib Arm (P-12)




All rights reserved.

No part of this document may be reproduced, stored in a retrieval system, or transmitted by any form or by any means, electronic, mechanical, photo-copying, recording, or otherwise, except as may be expressly permitted by the applicable copyright statutes or in writing by the Publisher.

What's In The Box


Please inspect the contents of your shipped package to ensure you have received everything that is listed below.



Front Section




LCD Monitor Arm



Middle Section



Weight Closers



End Section



Weight Shank



Tools



Central Post



Bag

INDEX

Sr. No	Particulars	Page No.
1	Assembling the Central Post	4
2	Assembling the Middle Jib Section	5-7
3	Assembling the Bush Setup	7-8
4	Assembling the End Jib Section	8-9
5	Assembling Front Jib Section	9-12
6	Monitor Assembly Setup	12-13
7	Final Setup	13

■ Assembling the Central Post

- Place the central post on top of a stand (**Not Included**).




- Insert the knob into the designated slot on the central post.




- Tighten the knob to secure the central post firmly on the stand.



- Using the 17mm spanner, loosen the bolt on the central post.
- Take out the bolt along with the washer.



- Unscrew and remove the screw from the central post bracket.



- Pull out the locking pin to complete the setup preparation.
- The central post is now ready for jib assembly.




■ Assembling the Middle Jib Section

- Open the Middle Section of the jib.



- Place the middle section of the jib on top of the central post and secure it.



- Insert the screw into the jib.




- Attach the washer and then the bolt to the screw.



- Tighten the bolt firmly using a 17mm spanner.
- Insert the locking pin into the slot.



- Secure the jib firmly to the central post.



- Remove the cap of the jib.



- Using a 6mm Allen key and 13mm spanner, loosen the bolt.
- Remove the bolt and washer.



- Remove the screw.



- Carefully open the jib to its full length as shown in the reference image.



- Reinsert the removed screw into the jib.
- Reattach the washer and bolt.



- Tighten the bolt using a 6mm Allen key.



- Place the cap back on the jib.





■ Assembling the Bush Setup

- Remove the bush caps from both ends of the bush.



- Using a 13mm spanner and a 6mm Allen key, loosen and remove the bolt and washer.




- Repeat the same process on the opposite side.
- Remove the screw from the bush.



- Align the bush with the jib section and insert the screw.




- Attach the washer to the screw.



- Then insert the bolt into it.



- Tighten the bolt using the 13mm spanner and 6mm Allen key, as shown in the image.



- Reattach the bush caps on both sides.



■ Assembling the End Jib Section


- Remove the screw cap from the middle section of the jib.



- Loosen the bolt using a 6mm Allen key and 13mm spanner, then remove the bolt and washer.



- Remove the screw from the middle section.
- Attach the end section of the jib to the middle section.



- The end section is attached to the middle section, as shown in the image.
- Insert the screw into the end section.



- Place the washer onto the screw.



- Insert the bolt and tighten it using the 13mm spanner and 6mm Allen key.



- Reattach the screw cap to secure the assembly.



- Remove the cap of the middle section.




■ Assembling the Front Jib Section


- Remove the cap of the middle section.



- Remove all four screw caps as shown in the image.




- Using a 6mm Allen key and 13mm spanner, loosen and remove the both bolt.



- Remove the corresponding screw.
- Attach the front section to the middle section as shown in the image



- Insert the both screw into the designated hole.




- Insert the corresponding bolt.
- Tighten the bolt using the 13mm spanner and 6mm Allen key.




- Place all four screw caps back onto the assembly.




- Route the front section wire to the end section.
- Loosen the turnbuckle on the end section.




- Loosen the turnbuckle on the end section and attach it to the front section wire.
- NOTE:** This wire is adjustable.



- The wire is now securely attached to the jib.



- Insert the weight shank into the end section hole.




- Attach the weight slide (**Not Included**) onto the shank.



- Attach the weight closers to the weight shank.
- NOTE:** The weight closers rotate 360° and slide automatically into position.



- The weight closers are now securely attached to the end section of the jib.



■ Monitor Assembly Setup

- Loosen the knob on the LCD monitor arm.



- Remove the knob and attach the monitor arm to the central post.



- Reattach and tighten the knob.



- Tighten the other knob on the LCD monitor arm as shown in the image.



- Mount the monitor (**Not Included**) onto the LCD monitor arm.
- Tighten the knob to secure the monitor.



- The monitor is now fully assembled on the LCD monitor arm.



PROAIM 12FT CAMERA CRANE JIB ARM ALL DRESSED UP AND READY TO GO!



(SHOWN WITH OPTIONAL ACCESSORIES)

Warranty: We offer a one-year warranty on our products from the date of purchase. During this period, we will repair the product free of charge for labor or parts. The warranty does **not** cover transportation costs or products that have been misused or accidentally damaged. All warranty repairs are subject to inspection and evaluation by our team.

Liability: We are not liable for any damage caused by third-party products, mishandling during transit, accidents, misuse, neglect, or unauthorized servicing of the product.

Contact Us: In case of any dissatisfaction, please contact us immediately. We are committed to providing the utmost support and care to ensure your satisfaction with our product.