

# PROAIM

## 18ft Camera Crane Jib Arm (P-18)




---

All rights reserved.

No part of this document may be reproduced, stored in a retrieval system, or transmitted by any form or by any means, electronic, mechanical, photo-copying, recording, or otherwise, except as may be expressly permitted by the applicable copyright statutes or in writing by the Publisher.

# What's In The Box

Please inspect the contents of your shipped package to ensure you have received everything that is listed below.



Section 1




Section 2



Section 3



Section 4



Section 5



Spanner (Size:17mm) x 2  
Spanner (Size:13mm) x 1



LCD Monitor Arm



Weight Closures



Knob



Allen Key (Size:6mm)



Weight Shank



Central Post



Plastic screw driver



Tools Bag



4 x Velcro (1ft each)



Bag

## INDEX

Sr. No	Particulars	Page No.
1	Central Post Assembly	4
2	Jib Sections Setup	4-5
3	Jib Section-4 Assembly	4-5
4	Bush Setup Assembly	6
5	Jib Section-3 Assembly	7-8
6	Jib Section-5 Assembly	8
7	Jib Section-2 Assembly	8-9
8	Jib Section-1 Assembly	9-10
9	Cable Routing & Counterweight Setup	11
10	LCD Monitor Assembly	12-13
11	Final Setup	14

## Central Post Assembly


- Place the central post on top of a stand **(Not Included)**.
- Insert the knob into the designated slot on the central post and tighten firmly.
- Remove the bolt from the central post for the next assembly step.



## Jib Sections Setup

### Jib Section-4 Assembly

- Open the Middle Section of the jib and place it atop the central post.
- Insert the screw through the jib section.
- Attach the washer followed by the bolt.



- Tighten securely using a 17mm and 13mm spanner.



- The jib is now firmly secured to the central post.



- Remove the cap and bolt.



- Carefully open the jib to its full length as shown in the reference image.



- Reinsert the removed screw into the jib.
- Tighten the screw using a 6mm Allen key.



## ■ Bush Setup Assembly

- Remove bush caps from both ends.



- Loosen and remove the bolt and washer using a 13mm spanner and 6mm Allen key.




- Align the bush with the jib section and insert the screw through the aligned holes.




- Place the washer onto the screw.
- Insert the bolt and secure it in position.



- Tighten the bolt firmly using the 13mm spanner and 6 mm Allen key, as shown in the image.





- Reattach the bush caps on both sides.



### Jib Section-3 Assembly


- Remove all protective caps from Section 3.




- Remove the bolts.




- Remove two bolts and loosen the remaining two bolts, as shown in the image.





- Attach Section 3 to Section 4.




- Insert all screws.



- Tighten all screws using a 6mm Allen key.




- Reattach the screw caps to secure the assembly.




## Jib Section-5 Assembly

- Remove the caps and bolts.



- Attach Section 5 to Section 3.




- Insert the screw.



- Place the washer onto the screw.



- Reattach all caps to complete the assembly.



## Jib Section-2 Assembly


- Remove the bush cap.



- Remove the bolts.





- Attach Section 2 to Section 5.




- Install the bolts and screws.



- Tighten the bolt using the 13mm spanner and 6mm Allen key.



- Reattach all four screw caps to secure the assembly.



## Jib Section- 1 Assembly


- Remove the cap from Section 2.



- Remove the cap and screw from Section 1.




- Attach Section 1 to Section 2.



- Install the bolt.





- Place the washer onto the screw.



- Tighten the bolt using a 13 mm spanner and a 6 mm Allen key.




- Reattach all caps securely.



## Cable Routing & Counterweight Setup

- Route the front-section wire to the end section.
- Loosen the turnbuckle on the end section.



- Attach the turnbuckle to the front-section wire.

**Note:** This wire is adjustable.



- The wire is now securely attached to the jib.



- Insert the weight shank into the designated hole on the end section.



- Attach the weights (**Not Included**) to the shank.



- Attach the weight closures to the weight shank.

**Note:** The weight closures rotate 360° and automatically slide into position.



## LCD Monitor Assembly

- Loosen the knob on the LCD monitor arm.



- Remove the knob and attach the monitor arm to the central post.



- Place the washer in position.
- Reattach and firmly tighten the knob.



- Install the camera bolt (Not Included) into the LCD Monitor Arm.



- Attach the monitor to the LCD Monitor Arm and tighten the camera bolt using a plastic screwdriver.



- Mount the monitor (Not Included) onto the LCD monitor arm.
- Tighten the knob to secure the monitor.



- The monitor is now fully assembled on the LCD monitor arm.



**PROAIM 18FT CAMERA CRANE JIB ARM  
ALL DRESSED UP AND READY TO GO!**



**(SHOWN WITH OPTIONAL ACCESSORIES)**

**Warranty:** We offer a one-year warranty on our products from the date of purchase. During this period, we will repair the product free of charge for labor or parts. The warranty does not cover transportation costs or products that have been misused or accidentally damaged. All warranty repairs are subject to inspection and evaluation by our team.

**Liability:** We are not liable for any damage caused by third-party products, mishandling during transit, accidents, misuse, neglect, or unauthorized servicing of the product.

**Contact Us:** In case of any dissatisfaction, please contact us immediately. We are committed to providing the utmost support and care to ensure your satisfaction with our product.